



RRF – Procedures



STEP 1 – PREPARATION

4. Verify:
 - a. Vent lines are not plugged.
 - b. Cooler tubes are not plugged.
 - c. The flush must be able to flow throughout the system.
5. Materials needed:
 - a. Enough **RRF** to fill the cooling system COMPLETELY.
 - b. **RRF** is ready to use and should never be diluted.
 - c. Enough DEIONIZED water to fill entire system THREE TIMES.
 - d. Two X 1" ball valves, one Installed on each side of block underneath rail.
 - e. Empty totes available to drain flush if needed.

- ### STEP 3 – FILL WITH RRF
- f. Have new water pump ready to install if needed.
 - g. Have new water pump ready to install if needed.
 6. Record water pump pressure and all temps.

STEP 2 – DRAIN COOLANT & DISPOSE

4. Shutdown, LOTO, and Remove Surge/Day Tank Cap.
5. Drain and dispose of old coolant.
6. Install ball valves. (leave open)

STEP 3 – FILL WITH PO4FIX

4. With Surge/Day Tank Cap removed, fill SLOWLY with **RRF** (Ready to Use) until overflow from Surge/Day Tank.
5. Record how much **RRF** is used to completely fill cooling system.
6. Replace Surge/Day Tank Cap.

STEP 4 – RUN AT FULL LOAD

3. Run Unit **2** hours, at temp, at full load.
4. Record water pump pressure and all temps.

STEP 5 – RINSE SURGE/DAY TANK

5. Record water pump pressure and all temps.
6. Shutdown, LOTO, and Remove Surge/Day Tank Cap.
7. While still HOT and FULL, Power wash Surge Tank with **STH - Surge Tank Hose**.
8. Let particles overflow until water runs clear. (@15-20 min)

STEP 6 – DRAIN FLUSH & DISPOSE

2. With Surge/Day Tank Cap removed, drain Flush via ball valve on each side of block underneath rail. (dispose as you would old coolant)

STEP 7 – RINSE OUT ALL PARTICULATES

4. Fill SLOWLY with deionized water until overflow from Surge/Day Tank.
5. Run Unit until up to temp and thermostats open.
6. Continue to pump in deionized water (2 x volume) until overflowing from the top at the Surge/Day Tank and ball valve on other side until clean.



STEP 8 - DRAIN & DISPOSE

3. Shutdown/LOTO/Remove
4. With Surge/Day Tank Cap removed, drain and dispose of rinse water.

STEP 9 – INSPECTION

2. Inspect water pump and thermostats and replace if needed.

STEP 10 – FILL WITH COOLANT

4. NEVER LEAVE OR RUN WITH WATER ONLY!
5. Fill with 50/50 coolant mix to winterize
6. Fill with [CoolAint](#) to Summerize

STEP 11 – REMEMBER

2. Quarterly coolant sampling.